

## Powder-Jack Photo Series - Attaching w/Hairpin

Bolt Mounted on Tunnel

POWDER-JACK IS EASILY ADAPTED TO MANY SNOWMOBILES. CHOOSE AN APPROPRIATE POSITION FOR THE BOLT, AND DRILL THE HOLE SO AS NOT TO DAMAGE ANY WIRING OR TUBING, THEN SECURE THE BOLT INTO PLACE USING THE HARDWARE PROVIDED.



Slide Jack onto Bolt

ADJUST THE JACK MECHNISM TO THE APPROPRIATE POSITION ON THE POLE, AND SLIP IT ONTO THE BOLT.



Slip Hairpin Through Bolt Hole

SECURE THE JACK WITH THE HAIRPIN PROVIDED .

